
Wire and mount the BST Doorphone

1. Remove the BST Doorphone's faceplate.
2. Determine if you want a surface or flush mount installation.

For a surface mount:

- Discard the flush mount gasket
- Verify the correct orientation of the gasket.
- Thread the wires through the center hole, then through the surface mount bracket.
- Fasten the surface mount bracket at the desired location on the wall.

OR

For a flush mount (into an electrical box embedded in the wall):

- Discard the surface mount bracket and gasket.
- Slide the flush mount gasket onto the main housing assembly.

